


YAMAHA

GENUINE

PARTS CATALOGUE


ALL TERRAIN VEHICLE



CYLINDER HEAD


Ref. No.	Part Number	Description	Qty	Remarks
1	36R-11111-00-00	HEAD, CYLINDER 1	1	
2	36R-11181-00-00	GASKET, CYLINDER HEAD 1CYLINDER HEAD 1	1	
3	NGK-BP6HS-00-00	PLUG, SPARK (NGK BP6HS) ..	1	
4	36R-11311-00-00	CYLINDER 1	1	
5	3PT-11351-00-00	GASKET, CYLINDER	1	
6	90116-06418-00	BOLT, STUD	4	
7	95701-06500-00	NUT, FLANGE	4	

CRANKSHAFT-PISTON



Ref. No.	Part Number	Description	Qty	Remarks
1	3L5-11400-01-00	CRANKSHAFT ASSEMBLY ...	1	
2	3L5-11412-00-00	. CRANK 1	1	
3	3L5-11422-01-00	. CRANK 2	1	
4	1YU-11681-00-00	. PIN, CRANK 1	1	
5	2E9-11651-00-00	. ROD, CONNECTING	1	
6	93310-416N7-00	. BEARING	1	
7	90280-03017-00	KEY, WOODRUFF	1	
8	92990-12600-00	WASHER, PLATE	1	
9	92901-12100-00	WASHER, SPRING	1	
10	95301-12700-00	NUT (95302-12700)	1	
11	93306-20326-00	BEARING	2	
12	93102-17067-00	OIL SEAL	1	
13	93102-23174-00	OIL SEAL	1	
14	36R-11631-00-A0	PISTON STD	1	
	36R-11635-00-00	PISTON 1 O/S 0.5	1	ALT. PART
	36R-11636-00-00	PISTON 2 O/S 0.0	1	ALT. PART
15	2E9-11633-00-00	PIN, PISTON	1	
16	36R-11601-00-00	PISTON RINGSET STD (STD) .	1	
	36R-11601-10-00	PISTON RINGSET 1ST (0.25MM O/S)	1	ALT. PART
	36R-11601-20-00	PISTON RINGSET 2ND (0.50MM O/S)	1	ALT. PART
17	93450-11021-00	CIRCLIP	2	
18	93310-210M0-00	BEARING, CYLINDRICAL	1	

36R110-4020




36R110-4030

OIL PUMP

Ref. No.	Part Number	Description	Qty	Remarks
1	36R-13101-00-00	OIL PUMP ASSEMBLY	1	
2	93101-10090-00	. OIL SEAL	1	
3	93210-26240-00	. O-RING	1	
4	90430-04004-00	. GASKET	1	
5	90149-04135-00	. SCREW	1	
6	384-13138-00-00	. PLATE, ADJUSTING	1	
7	90170-10105-00	. NUT	1	
8	90401-10029-00	. BOLT, UNION	1	
9	3L5-13124-00-00	. GEAR, WORM WHEEL (56T)	1	
10	91690-30014-00	. PIN, SPRING (91609-30014-00)	1	
11	99080-07600-00	. CIRCLIP	1	
12	3L5-13161-00-00	PIPE, DELIVERY 1	1	
13	90468-02033-00	CLIP	2	
14	98580-05020-00	SCREW, PAN HEAD	1	
15	98501-05035-00	SCREW, PAN HEAD	1	
16	17J-15416-00-00	COVER 1 (3L5-15416-00)	1	
17	3L5-15426-00-00	COVER, OIL PUMP 2	1	
18	97780-50514-00	SCREW, TAPPING	1	


AIR CLEANER



36R110-4040

Ref. No.	Part Number	Description	Qty	Remarks
1	3L5-13610-00-00	REED VALVE ASSEMBLY	1	
2	3L5-13613-00-00	. REED, VALVE	1	
3	3L5-13616-00-00	. STOPPER, REED VALVE	1	
4	98580-03010-00	. SCREW, PAN HEAD	2	
5	92990-03100-00	. WASHER, SPRING	2	
6	3L5-13624-00-00	. PLATE, REED VALVE	1	
7	3HK-13621-00-00	GASKET, VALVE SEAT	1	
8	3L5-13622-10-00	GASKET, VALVE SEAT	1	
9	36R-13555-01-00	MANIFOLD, INTAKE	1	
10	98580-06020-00	SCREW, PAN HEAD	4	
11	36R-14411-00-00	CASE, AIR CLEANER 1	1	
12	36R-14412-00-00	CAP, CLEANER CASE 1	1	
13	36R-14451-00-00	ELEMENT, AIR CLNR	1	
14	97780-50125-00	SCREW, TAPPING	1	
15	36R-14453-00-00	JOINT, AIR CLNR 1	1	
16	36R-14455-00-00	BAND	1	
17	90480-14100-00	GROMMET	1	
18	90467-20023-00	CLIP	1	
19	90119-06043-00	BOLT, WITH WASHER	1	

CARBURETOR




Ref. No.	Part Number	Description	Qty	Remarks
1	36R-14101-00-00	CARBURETOR ASSEMBLY 1	1	
2	3L5-14184-00-00	. GASKET, FLOAT CHAMBER	1	
3	3G2-14231-18-00	. JET, MAIN (90)	1	U.R.
	3G2-14231-19-00	. JET, POWER (95)	1	U.R.
	3G2-1423A-69-00	. JET, MAIN 92 5	1	U.R. STD
4	3L7-14141-18-00	. NOZZLE, MAIN	1	
5	3L5-14142-40-00	. JET, PILOT (# 40)	1	
6	98503-04014-00	. SCREW, PAN HEAD	4	
7	92901-04600-00	. WASHER, PLATE	4	
8	3L5-14198-00-00	. GASKET	1	
9	17L-14106-00-00	. CABLE ADJUST SCREW SET	1	
10	1R0-14169-00-00	. CAP	2	
11	3L6-14185-01-00	. FLOAT	1	
12	3L5-14190-01-00	. NEEDLE VALVE ASSEMBLY	1	
13	603-14186-00-00	. PIN, FLOAT	1	
14	3L5-14112-40-00	. VALVE, THROTTLE 1	1	
15	36R-1490J-00-00	. NEEDLE SET	1	
16	174-14131-01-00	. SPRING, THROTTLE VALVE	1	
17	36R-14103-00-00	. THROTTLE SCREW SET	1	
18	36R-14171-00-00	. PLUNGER, STARTER	1	
19	127-14135-00-00	. SPRING, PLUNGER	1	
20	98580-05012-00	. SCREW, PAN HEAD	1	
21	92990-05100-00	. WASHER, SPRING	1	
22	36R-14104-00-00	. AIR SCREW SET	1	
23	95380-05600-00	. NUT	1	
24	98501-05030-00	. SCREW, PAN HEAD	1	
25	90445-05024-00	. HOSE (835-13171-00)	1	
26	17L-14104-00-00	. AIR SCREW SET	1	
27	1V3-14271-00-00	. INSULATOR	1	

36R110-4050

CONTINUED ON NEXT FRAME ►


CARBURETOR

Ref. No.	Part Number	Description	Qty	Remarks
28	1M3-14997-00-00	. SEAL	1	
29	18M-14144-08-00	. JET, STARTER	1	




36R110-4050

EXHAUST




Ref. No.	Part Number	Description	Qty	Remarks
1	36R-14611-01-00	PIPE, EXHAUST L	1	
2	36R-14714-01-00	GASKET, MUFFLER	1	
3	36R-14711-01-00	MUFFLER 1 (36R-14711-00) ...	1	
4	95816-08035-00	. BOLT, FLANGE	1	
5	90201-07078-00	. WASHER, PLATE	1	
6	36R-14753-00-00	SILENCER, EXHAUST	1	
7	4X4-14752-00-00	. PIPE, OUTLET	1	
8	98580-06008-00	. SCREW, PAN HEAD	1	
9	92995-06100-00	. WASHER, SPRING	1	
10	90201-061A5-00	. WASHER, PLATE	1	
11	36R-14613-00-00	GASKET, EXST PIPE (UNRESTRICTED)	1	U.R.
	36R-14623-00-00	GASKET, EXST PIPE (RESTRICTED)	1	U.R.
12	4X4-14714-00-00	GASKET, MUFFLER	1	
13	90467-22048-00	CLIP	1	
14	95816-08016-00	BOLT, FLANGE	2	
15	95816-06016-00	BOLT, FLANGE	1	
16	90153-06057-00	SCREW, hexagon	2	
17	90201-081A6-00	WASHER, PLATE	2	
18	92901-08600-00	WASHER, PLATE	1	YT60N
19	36R-14787-00-00	CAP, SILENCER	1	YT60N



CRANKCASE

Ref. No.	Part Number	Description	Qty	Remarks
1	4X4-15111-00-00	CRANKCASE 1	1	
2	99510-12016-00	PIN, DOWEL	2	
3	98580-06545-00	SCREW PAN HEAD	8	
4	3L5-15121-00-00	CRANKCASE 2	1	
5	3L5-15128-00-00	HOLDER	1	
6	98580-06012-00	SCREW, PAN HEAD (92501-06012-00)	1	
7	2E9-15316-00-00	DAMPER, ENGINE MOUNT 1 ..	2	
8	4X4-15421-00-00	COVER, CRANKCASE R	1	
9	4X4-15491-00-00	PROTECTOR	1	
10	99510-12016-00	PIN, DOWEL	2	
11	3L5-15451-10-00	GASKET, CRANKCASE COVER 1	1	
12	98506-06035-00	SCREW, PAN HEAD	2	
13	98506-06025-00	SCREW, PAN HEAD	3	
14	90153-06053-00	SCREW, HEXAGON	1	
15	90105-08103-00	BOLT, WASHER BASED	1	
16	90201-08087-00	WASHER, PLATE	1	
17	4J2-15363-00-00	PLUG, OIL	1	
18	93210-14104-00	O-RING	1	
19	90338-26136-00	PLUG	1	
20	4X4-15484-00-00	CLAMP 2	1	
21	90445-05773-00	HOSE	1	
22	3L5-17112-01-00	BUSH 1	1	


GENERATOR



Ref. No.	Part Number	Description	Qty	Remarks
1	36R-85550-M0-00	ROTOR ASSEMBLY	1	
2	1HN-85560-M0-00	BASE ASSEMBLY (36R-85560-M0)	1	
3	36R-85520-M0-00	. COIL, CHARGE	1	
	4Y4-85520-M0-00	. COIL, CHARGE	1	
4	4X4-81313-M0-00	. COIL, LIGHTING 1	1	
5	3L5-85580-M0-00	. COIL, PULSER	1	
6	90461-05036-00	. CLAMP	1	
7	98580-04010-00	. SCREW, PAN HEAD	1	
8	92901-04600-00	. WASHER, PLATE	1	
9	98511-04006-00	. SCREW, PAN HEAD	2	
10	92901-04600-00	. WASHER, PLATE	2	
11	98511-04012-00	. SCREW, PAN HEAD	2	
12	98506-04018-00	. SCREW, PAN HEAD	2	
13	36R-8131X-M0-00	LEAD WIRE ASSEMBLY	1	
14	98701-06014-00	SCREW, FLAT HEAD	2	




36R110-4240



STARTER

Ref. No.	Part Number	Description	Qty	Remarks
1	36R-15710-00-00	STARTER ASSEMBLY	1	
2	36R-15741-01-00	. PAWL, DRIVE	1	
3	36R-15713-00-00	. SPRING, STARTER	1	
4	36R-15715-00-00	. SPRING, FRICTION	1	
5	36R-15767-00-00	. SPRING	1	
6	36R-15716-00-00	. PLATE, DRIVE	1	
7	97013-06012-00	. BOLT	1	
8	36R-15751-00-00	. ROPE, STARTER	1	
9	36R-15755-00-00	. HANDLE, STARTER	1	
10	36R-15726-01-00	. WASHER, FLAT	1	
11	36R-15779-00-00	. COVER	1	
12	36R-15711-00-00	. CASE, STARTER	1	
13	36R-15714-00-00	. DRUM, SHEAVE	1	
14	36R-15723-00-00	PULLEY, STARTER	1	
15	98506-05008-00	SCREW, PAN HEAD	3	
16	97011-06010-00	BOLT (97002-06010)	3	


CLUTCH



Ref. No.	Part Number	Description	Qty	Remarks
1	3L5-16111-00-00	GEAR, PRIMARY DRIVE (33T)	1	
2	3L5-16115-00-00	ABSORBER 1	1	
3	3L5-16125-00-00	ABSORBER 2	1	
4	3L5-16114-00-00	PLATE, THRUST 2	1	
5	3L5-16181-01-00	SPACER 1	1	
6	90387-16730-00	COLLAR	1	
7	90282-05034-00	KEY, STRAIGHT	1	
8	90208-10012-00	WASHER, CONICAL SPRING	1	
9	95701-10500-00	NUT, FLANGE	1	
10	99009-16400-00	CIRCLIP	1	
11	90201-16383-00	WASHER, PLATE	1	
12	36R-16620-02-00	CLUTCH CARRIER ASSEMBLY (36R-16620-01)	1	
13	3L5-16628-02-00	. WASHER	2	
14	2T4-16629-00-00	. DAMPER, CLUTCH WEIGHT	2	
15	3L5-16627-02-00	. SPRING, CLUTCH WEIGHT 2	2	
16	36R-16633-00-00	. SHAFT, CLUTCH WEIGHT	4	
17	36R-16611-01-00	HOUSING, CLUTCHCOMP	1	
18	99009-16400-00	CIRCLIP	1	


FWD
36R110-4090

TRANSMISSION



Ref. No.	Part Number	Description	Qty	Remarks
1	3L5-17410-00-00	MAIN AXLE COMP. (15T)	1	
2	3L5-17531-00-00	SHIM, PINION	1	
3	3L5-17471-00-00	PLATE, COVER	1	
4	3L5-17473-00-00	STOPPER	1	
5	91316-06016-00	BOLT, SOCKET HEAD	2	
6	3L5-17550-00-00	DRIVEN PINION ASSEMBLY ..	1	
7	3L5-17537-00-00	SHIM, THRUST	1	
8	3L5-17442-00-00	COLLAR, DISTANCE	1	
9	90149-45134-00	SCREW	1	
10	93102-15267-00	OIL SEAL	1	
11	3L5-13178-00-00	GEAR, PUMP DRIVE	1	

FRAME




Ref. No.	Part Number	Description	Qty	Remarks
1	99999-01712-00	FRAME SET (36R)	1	YAMAHA BLK
2	95601-10200-00	NUT, SELF-LOCKING	1	
3	90105-10130-00	BOLT, WASHER BASED	1	
4	(36R-21471-00-00)	PROTECTOR, ENGINE	1	
5	90105-06301-00	BOLT, WASHER BASED	2	

36R110-4110

FRONT FENDER


Ref. No.	Part Number	Description	Qty	Remarks
1	36R-21511-00-00	FENDER, FRONT	1	U.R. COMP. YELLOW
	36R-21511-20-00	FENDER, FRONT	1	U.R. SKY BLUE
	36R-21511-40-00	FENDER, FRONT (CPR)	1	
2	90119-06043-00	BOLT, WITH WASHER	2	
3	36R-21521-00-00	FLAP, FRONT FENDER	1	
4	90119-06043-00	BOLT, WITH WASHER	2	
5	(36R-21570-20-00)	GRPHC SET, FRT FNDR	1	
	36R-21570-00-00	GRPHC SET, FRT FNDRFRONT FENDER	1	
	36R-21570-01-00	GRPHC SET, FRT FNDRFRONT FENDER	1	




36R110-4120

REAR FENDER

Ref. No.	Part Number	Description	Qty	Remarks
1	36R-21611-00-00	FENDER, REAR	1	U.R. COMP. YELLOW
	36R-21611-20-00	FENDER, REAR	1	U.R. SKY BLUE
	36R-21611-40-00	FENDER, REAR (CPR)	1	
2	90119-06056-00	BOLT, WITH WASHER	3	
3	90480-16233-00	GROMMET	4	
4	5V7-21747-00-00	DAMPER	2	
5	36R-2163G-00-00	EMBLEM 1	2	U.R. FOR CPY
	36R-2163G-20-00	EMBLEM 1	2	
6	(36R-21659-00-00)	LABEL, SAFETY	1	
7	(36R-21781-00-00)	EMBLEM 1	1	U.R. FOR CPY
	36R-21781-20-00	EMBLEM 1	1	U.R. FOR SYB
	36R-21781-40-00	EMBLEM 1 (FOR CPR)	1	
8	(36R-21782-40-00)	EMBLEM 2 (FOR CPR)	1	
	36R-21782-00-00	EMBLEM 2	1	U.R. FOR CPY
	36R-21782-20-00	EMBLEM 2	1	U.R. FOR SYB
9	36R-21785-20-00	EMBLEM 5	1	
	4U3-21785-00-00	EMBLEM 5	1	U.R. FOR CPY
10	22W-24181-00-00	DAMPER, LOCATING 1	2	
11	50W-28100-00-00	TOOL KIT	1	
12	116-82131-00-00	BAND, BATTERY	1	



SWING ARM




Ref. No.	Part Number	Description	Qty	Remarks
1	3L5-22110-00-35	REAR ARM	1	SILVER
2	90101-08461-00	BOLT	6	
3	92990-08100-00	WASHER, SPRING	6	


FWD
36R110-4150

DRIVE SHAFT

Ref. No.	Part Number	Description	Qty	Remarks
1	36R-46151-00-00	HOUSING, DR SHAFT	1	
2	36R-46120-01-00	DRIVE PINION ASSEMBLY	1	
3	3L5-46127-00-00	SHIM, DRIVE PINION	1	
4	93306-20111-00	BEARING (B6201)	1	
5	90149-35133-00	SCREW	1	
6	90560-25185-00	SPACER	1	
7	36R-46110-01-00	RING GEAR ASSEMBLY (36R-46110-00)	1	
	93316-00503-00	BEARING, CYLINDER.#16 (93316-00504)	1	
9	93102-25311-00	OIL SEAL (FPJ 25-44-8 TS)	1	
10	93211-07492-00	O-RING	1	
11	95811-06016-00	BOLT, FLANGE (95801-06016)	6	
12	583-15371-00-00	BREATHER	1	
13	90445-07769-00	HOSE	1	
14	15L-46171-00-00	SHAFT DRIVE ASSEMBLY (3L5-46171-00)	1	
15	90501-60556-00	. SPRING, COMPRESSION	1	
16	15L-18473-00-00	. RETAINER, SPRING	1	
17	93440-17138-00	. CIRCLIP	1	



STEERING




36R110-4170

Ref. No.	Part Number	Description	Qty	Remarks
1	36R-23100-00-26	FRT.FORK ASSEMBLY YELOASSEMBLY (36R-23100-00)	1	YELLOW
	36R-23100-00-G8	FRT.FORK ASSEMBLY BLUEASSEMBLY	1	
2	36R-23110-00-00	. INNER TUBE 1KCOMP. 1	2	
3	(36R-23141-00-00)	SPRING, FRONT FORK	2	
4	25K-23143-00-00	. SEAT, SPRING LOWER	4	
5	3L6-23195-00-00	. RUBBER	2	
6	296-23414-00-00	. RACE, BALL 4	1	
7	(36R-23435-00-00)	CROWN, HANDLE	1	
8	90105-10006-00	BOLT, WASHER BASED	3	
9	90209-10021-00	WASHER, SPEC'L SHAP	1	
10	90201-10742-00	WASHER, PLATE	2	
11	36R-23412-00-00	RACE, BALL 2	1	
12	22F-23412-01-00	RACE, BALL 2	1	
13	3PT-23411-00-00	RACE, BALL 1	1	
14	93505-32002-00	BALL	26	
15	93503-16010-00	BALL 3/ 6	22	


OIL TANK

Ref. No.	Part Number	Description	Qty	Remarks
1	36R-21751-00-00	TANK, OIL	1	
2	2N3-21771-01-00	BODY, CAP	1	
3	90445-09226-00	HOSE	1	
4	90467-08003-00	CLIP	2	
5	90119-06056-00	BOLT, WITH WASHER	2	



36R110-4140

FUEL TANK





Ref. No.	Part Number	Description	Qty	Remarks
1	36R-24110-00-00	FUEL TANK	1	
2	90480-18290-00	GROMMET	2	
3	90387-066J1-00	COLLAR	2	
4	97021-06125-00	BOLT, HEXAGON (97322-06125)	1	
5	90201-06697-00	WASHER, PLATE	2	
6	95701-06500-00	NUT, FLANGE	1	
7	4X4-24610-00-00	CAP ASSEMBLY	1	
8	1L4-24615-00-00	. GASKET, PLATE 1	1	
9	1L4-24616-00-00	. GASKET, PLATE 2	1	
10	36R-24500-01-00	FUEL COCK ASSEMBLY 1	1	
11	(4X8-24523-00-00)	FUEL COCK ASSEMBLY	1	
12	4X8-24534-00-00	. SEAL, COCK	1	
13	4X8-24512-00-00	. O-RING	1	
14	90202-05187-00	WASHER, PLATE	2	
15	90149-06011-00	SCREW	2	
16	90445-09085-00	HOSE	1	
17	90467-08003-00	CLIP	2	
18	3R0-24181-00-00	DAMPER, LOCATING 1	1	

36R110-3180


SEAT

Ref. No.	Part Number	Description	Qty	Remarks
1	36R-W2471-00-00	SINGLE SEAT ASSEMBLY ...	1	U.R. RED
2	36R-24711-00-00	. COVER, SINGLE SEAT	1	
3	371-27114-00-00	STOPPER, MAIN STAND	2	
4	36R-W2471-20-00	SINGLE SEAT ASSEMBLY ...	1	U.R. BLUE
5	36R-24711-20-00	. COVER, SINGLE SEAT	1	
6	371-27114-00-00	STOPPER, MAIN STAND	2	
7	36R-W2471-10-00	SINGLE SEAT ASSEMBLY ...	1	UR YELLOW
8	36R-24711-10-00	. COVER, SINGLE SEAT	1	
9	371-27114-00-00	STOPPER, MAIN STAND	2	
10	36R-24776-00-00	LEVER, SEAT	1	
11	90508-20646-00	SPRING, TORSION	1	
12	90249-08146-00	PIN, SPEC'L SHAPE	1	
13	99009-06600-00	CIRCLIP	1	



36R110-5190


FRONT WHEEL



Ref. No.	Part Number	Description	Qty	Remarks
1	36R-25111-00-00	HUB, FRONT	1	
2	93306-00108-00	BEARING	2	
3	90560-12300-00	SPACER, BRNG.	1	
4	36R-25116-00-00	FLANGE, SPACER 2	1	
5	36R-25180-01-35	WHEEL, FRONT (36R-25180-00-35)	1	SILVER
6	94107-063E8-00	15X7.00-6 KT465TL	1	DUNLOP
7	93900-00030-00	VALVE, RIM	1	DUNLOP
8	95333-08600-00	NUT	3	
9	92990-08200-00	WASHER, PLAIN	3	
10	92990-08100-00	WASHER, SPRING	3	
11	36R-25181-00-00	AXLE, WHEEL	1	
12	36R-25183-00-00	COLLAR, WHEEL	2	
13	36R-25118-00-00	COVER, HUB DUST	2	
14	90171-12023-00	NUT, CASTLE	1	
15	91401-25030-00	PIN, COTTER	1	

36R110-4200


REAR WHEEL



Ref. No.	Part Number	Description	Qty	Remarks
1	36R-25383-00-00	COLLAR, WHEEL	2	
2	36R-25181-01-35	UNAVAILABLE IN PRICE BOOK (36R-25180-00-35)	2	SILVER
3	94107-063E8-00	15X7.00-6 KT465TL	2	DUNLOP
4	93900-00030-00	VALVE, RIM	2	DUNLOP
5	92990-08100-00	WASHER, SPRING	6	
6	92990-08200-00	WASHER, PLAIN	6	
7	95333-08600-00	NUT	6	
8	36R-25311-00-00	HUB, REAR	1	
9	93306-00519-00	BEARING	2	
10	90560-25307-00	SPACER, BEARING	1	
11	36R-W2536-00-00	BRAKESHOE SET-2PCS	2	
12	90506-18288-00	SPRING, TENSION	2	
13	5G3-25351-02-00	CAMSHAFT	1	
14	36R-25355-00-00	LEVER, CAMSHAFT	1	
15	90101-06278-00	BOLT	1	
16	95380-06600-00	NUT, HEXAGON	1	
17	90480-10068-00	GROMMET	1	
18	93210-12790-00	O-RING	2	
19	93102-35318-00	OIL SEAL	1	
20	(36R-46114-00-00)	PLATE, COVER	1	
21	91311-06016-00	BOLT	3	
22	36R-2531E-00-00	DRUM BRAKE	1	
23	36R-25715-01-00	COVER 1	1	
24	90179-23439-00	NUT, SPEC'L SHAPE	1	
25	90215-23227-00	WASHER, LOCK	1	
26	36R-25367-00-00	COVER, HUB DUST	1	
27	90171-12039-00	NUT, CASTLE	2	
28	90201-126A7-00	WASHER, PLATE	2	


CONTINUED ON NEXT FRAME ►

REAR WHEEL



36R110-4210

Ref. No.	Part Number	Description	Qty	Remarks
29	91401-25030-00	PIN, COTTER	2	
30	90119-10078-00	BOLT, WITH WASHER	4	
31	90201-104G0-00	WASHER, PLATE	4	
32	36R-2219X-00-00	COVER	1	
33	97011-06016-00	BOLT	3	
34	92995-06100-00	WASHER, SPRING	3	
35	90201-061A5-00	WASHER, PLATE	3	
36	93210-25642-00	O-RING	1	
37	98580-06012-00	SCREW, PAN HEAD (92501-06012-00)	3	
38	92995-06100-00	WASHER, SPRING	3	




HANDLEBAR-CABLE

Ref. No.	Part Number	Description	Qty	Remarks
1	21V-26374-00-00	. END, CABLE 3	1	YT60L
	36R-26111-00-00	HANDLEBAR	1	
2	91609-30010-00	. PIN, SPRING	1	YT60L
	95611-08100-00	NUT, U	2	
3	2E9-26129-00-00	WASHER	2	
4	4X4-26241-00-00	GRIP (LEFT)	1	
5	4X4-26241-00-00	GRIP (LEFT)	1	
6	21W-26261-00-00	CONNECTOR, CABLE	1	
7	36R-26311-00-00	CABLE, THROTTLE 1	1	
8	36R-26312-00-00	CABLE, THROTTLE 2	1	
9	36R-26321-00-00	CABLE, PUMP	1	
10	21W-26262-00-00	CAP, CABLE CONNECTOR ...	1	
11	21W-26263-00-00	PIECE, CONNECTING	1	
12	90167-03004-00	SCREW, TAPPING	2	
13	36R-26331-00-00	CABLE, STARTER 1	1	
14	36R-26351-00-00	CABLE, BRAKE	1	
15	90501-10245-00	SPRING, COMPRESSION	1	
16	90179-06411-00	NUT, SPECIAL SHAPE	1	
17	90249-12008-00	PIN	1	
18	36R-26124-00-00	PROTECTOR, HDLBR	1	U.R. RED
	36R-26124-20-00	PROTECTOR, HDLBR	1	U.R. BLUE
	36R-26124-40-00	PROTECTOR, HDLBR	1	U.R. YELLOW
19	437-83936-11-00	BAND, SWITCH CORD	2	


STAND-FOOTREST

Ref. No.	Part Number	Description	Qty	Remarks
1	36R-27411-00-00	FOOTREST 1	1	
2	36R-27421-00-00	FOOTREST 2	1	
3	4X4-27413-00-00	COVER, FOOTREST	1	
4	4X4-27413-00-00	COVER, FOOTREST	1	
5	(95826-08012-00)	BOLT, FLANGE	1	
6	(95826-08012-00)	BOLT, FLANGE	1	
7	95816-08025-00	BOLT, FLANGE	1	
8	95816-08025-00	BOLT, FLANGE	1	



ELECTRICAL 1


Ref. No.	Part Number	Description	Qty	Remarks
1	36R-85540-M0-00	CDI UNIT ASSEMBLY	1	
2	98503-06014-00	SCREW, PAN HEAD (92501-06015)	1	
3	92995-06100-00	WASHER, SPRING	1	
4	90201-061A5-00	WASHER, PLATE	1	
5	36R-85590-M0-00	CONTROL UNIT ASSEMBLY	1	
6	4J2-85546-00-00	BAND	1	
7	5M0-82310-M0-00	IGNITION COIL ASSEMBLY	1	
8	97313-06016-00	BOLT	1	
9	90153-06034-00	SCREW, HEXAGON	1	
10	56J-82370-00-00	PLUG CAP ASSEMBLY	1	
11	36R-82590-01-00	WIRE HARNESS ASSEMBLY	1	



36R110-4250

ELECTRICAL 2

Ref. No.	Part Number	Description	Qty	Remarks
1	53L-83912-00-00	LEVER L	1	
2	90149-05120-00	SCREW, SPEC'L SHAPE	1	
3	95601-05100-00	NUT, U	1	
4	36R-83976-02-00	SWITCH, HANDLE 1 (36R-83976-01)	1	
5	98506-05025-00	. SCREW, PAN HEAD	2	
6	36R-2625G-00-00	. LEVER, THROTTLE	1	
7	95316-05700-00	. NUT	1	
8	98506-05020-00	. SCREW, PAN HEAD	1	
9	95380-05600-00	. NUT	1	
10	92990-05100-00	. WASHER, SPRING	1	
11	90508-08655-00	. SPRING, TORSION	1	
12	437-83936-01-00	BAND, SWITCH CORD	1	
13	437-83936-11-00	BAND, SWITCH CORD	1	
14	36R-82550-00-00	STOP SWITCH ASSEMBLY ...	1	
15	36R-82556-00-00	. DAMPER, STOPPER	1	
16	663-82557-00-00	. NUT	1	
17	36R-83930-00-00	LEVER LOCK ASSEMBLY	1	



36R110-4260